

BLIND HEM FOOT ADJUSTABLE

Machine settings:

Stitch:	Blind hem stitch
Thread tension:	1 - 4
Stitch length:	2 - 4
Stitch width:	5

Turn the guide screw and move the sliding guide next to the folded edge. Sew, guiding the folded edge along the sliding guide.

For a professional looking hem fold the fabric, reducing the lip to a scant 0.3 cm (1/8"). As you sew, the right hand stitch will fall off the fabric edge forming a chain stitch.

Draadspanning:	1 - 4
Steeklengte:	2 - 4
Steekbreedte:	5

Blindstichfuss für Modelle mit CB-Greifer	
Stichprogramm:	Blindstich
Fadenspannung:	1 - 4
Stichlänge:	2 - 4
Stichbreite:	5

Pied ourlet invisible pour machine avec crochet horizontal

Réglages de la machine:

Point:	Point ourlet invisible
Tension du fil:	1 - 4
Longueur:	2 - 4
Largeur:	5

Helman piilo-ommeljalka pystyvuola malleihin

Koneen asetukset:

Ommel:	Helman piilo-ommel
Langan kireys:	1 - 4
Piston pituus:	2 - 4
Piston leveys:	5

Pie para hacer dobladillos invisibles. Para máquinas de bobina frontal.

Ajustes de la máquina:

Puntada:	doblado invisible
Tensión de hilo:	1 - 4
Largo de puntada:	2 - 4
Ancho puntada:	5

Piedino per orlo invisibile – per Modelli con crochet verticale

Impostazione macchina:

Punto:	Punto invisibile
Tensione filo:	1 - 4
Lunghezza punto:	2 - 4
Larghezza punto:	5

